

SPEED SEAT MOUNTING INSTRUCTIONS

2009+ HONDA CBR1000 RR

PART # SPD-800-01

NOTE: THIS IS A PAD ONLY PRODUCT DESIGNED TO BE INSTALLED ON THE STOCK SEAT PAN.



REMOVE STOCK SEAT.



PULL OFF SIDE PANEL STARTING AT THE BACK POINT. REMOVE BOTH PHILLIPS SCREWS (ONE EACH SIDE).



WITH A PUNCH OR FLAT HEAD, PRY UP THE STAPLES. USE PLIERS TO REMOVE THEM. REMOVE COVER AND FOAM.



PLACE THE SPEED SEAT ON TOP OF THE PAN, MAKING SURE IT IS CORRECTLY ALIGNED AND FITTED TOGETHER. HOLD THE AREA TO BE MARKED WITHOUT SHIFTING THE PAD AROUND. MARK A CENTER SPOT IN EACH HOLE. IMPORTANT: CHECK FOR CORRECT ALIGNMENT BEFORE DRILLING.



TRY TO DRILL EACH HOLE STRAIGHT INTO THE FACE OF THE SURFACE. TRIM OFF ANY LOOSE FLASHING AROUND THE NEW HOLE.



SNUG EACH NUT BUT DO NOT OVER TIGHTEN AND SMASH SEAT MATERIAL TOO MUCH. REINSTALL SEAT. NOW GO RIDE AND GET LOOKS!



1-800-749-SEAT · 904-354-4531
FAX 904-354-7979
WWW.SargentCycle.COM

SARGENT
CYCLE PRODUCTS