

**Tools Required:**

1. 3mm Allen wrench (included)

**NOTE:** This gap filler panel kit is designed for BMW R1300 GSA Trophy/Enduro motorcycle package owners whose motorcycle is equipped with the LOW PROFILE rear seat, and who wish to replace their rear seat with a Sargent seat.

**Kit Parts:**

- Qty 1 - 3 mm Allen wrench (not shown)
- Qty 2 - U-nuts
- Qty 1 - Upholstered panel
- Qty 4 - Plastic spacers

**Installation:**

1. Install U-nuts A onto seat base by pushing them in place with the treaded side toward the back of the seat.
2. Install panel B using four spacers C and two screws D as shown.



**CAUTION:** Do not force screws when mounting. Avoid cross threading. The screws should be started by hand first, then the wrench can be used to tighten. Do not over tighten!