

⚠ WARNING:
READ THE INSTRUCTIONS IN
THEIR ENTIRETY BEFORE
BEGINNING INSTALLATION.

TOOLS REQUIRED:
NONE

SEAT INSTALLATION:

1. DO NOT REMOVE LARGE BOLTS ON SEAT **A**.
2. SLIP COWL **B** OVER BOLTS **A**.
3. INSTALL THUMB SCREWS AND WASHERS **C** PROVIDED THROUGH COWL INTO BOLTS **A** ON SEAT AS SHOWN IN PHOTO **D**.
4. SNUG THUMB SCREWS

