

**! WARNING**

READ THE INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING INSTALLATION.

**BMW K-1600 GRAND AMERICA  
SEAT INSTALLATION GUIDE**

**Included in this kit:**

1. Metal Bracket MB-674-1 x1

**Tools Required:**

1. OEM Supplied Torx wrench.

**SPECIAL NOTE:** Always mind the heat cable when removing the seat!

**Installation:**

1. Remove the OEM seat.
2. Install Sargent supplied metal bracket **(B)** by removing the OEM screws **(A)**, inserting bracket and reinstalling the OEM screws **(A)**.
3. Install the Sargent seat just as you would the OEM seat.

