

⚠ IMPORTANT:

Read ALL instructions carefully before beginning installation.

This product requires you to transfer the OEM rear seat adjustment/latch plate to your new Sargent seat.

Tools Required: T-20 Torx

STEPS:

1. Remove the OEM rear seat.
2. Disengage the heat-plug **A** (if equipped) from its holder by turning it clock-wise approximately 10 degrees and pulling it backward. Make note of the wire routing **B**. See Fig 1.
3. Remove the adjustment/latch plate **B** from the OEM seat by removing the four screws, springs and washer sets. Set aside and make note of the order for reinstallation.
4. Install the OEM adjustment plate **C** onto the SARGENT seat by reversing the above procedure. Snug, do not over tighten. Fig 2.
5. Install your Sargent seats on the motorcycle. The Sargent rear seat will operate just like the stock rear seat, with fore and aft adjustment achieved by lifting it and sliding it back and forth into one of two positions.
6. Hit the road and enjoy the ride!

Plug and Play Heated Seats:

If your Sargent seats are heated, they will have OEM compatible plugs. Additionally the passenger seat will have a two-level heat control switch accessible to the passenger underneath the right side while seated.

