

**HONDA RC51**  
**INSTALLATION INSTRUCTIONS**  
**PART # WS-516**

Washers are provided and are to be used with the original equipment 6mm seat bolts. These washers should be installed onto the bolts before bolt installation.

When installing the seat always slide it BACKWARDS FIRST with the rear bolt brackets sliding under the body work. Next, applying gentle pressure, push the seat forward engaging the tongues. Install the bolts by gently pulling back the foam to access the bolt locations.

**HONDA RC51**  
**INSTALLATION INSTRUCTIONS**  
**PART # WS-516**

Washers are provided and are to be used with the original equipment 6mm seat bolts. These washers should be installed onto the bolts before bolt installation.

When installing the seat always slide it BACKWARDS FIRST with the rear bolt brackets sliding under the body work. Next, applying gentle pressure, push the seat forward engaging the tongues. Install the bolts by gently pulling back the foam to access the bolt locations.

**HONDA RC51**  
**INSTALLATION INSTRUCTIONS**  
**PART # WS-516**

Washers are provided and are to be used with the original equipment 6mm seat bolts. These washers should be installed onto the bolts before bolt installation.

When installing the seat always slide it BACKWARDS FIRST with the rear bolt brackets sliding under the body work. Next, applying gentle pressure, push the seat forward engaging the tongues. Install the bolts by gently pulling back the foam to access the bolt locations.

**HONDA RC51**  
**INSTALLATION INSTRUCTIONS**  
**PART # WS-516**

Washers are provided and are to be used with the original equipment 6mm seat bolts. These washers should be installed onto the bolts before bolt installation.

When installing the seat always slide it BACKWARDS FIRST with the rear bolt brackets sliding under the body work. Next, applying gentle pressure, push the seat forward engaging the tongues. Install the bolts by gently pulling back the foam to access the bolt locations.